



Technical Data Sheet

DOW™ HDPE DMDA-8007 Health+ High Density Polyethylene Resin

Overview

DOW™ DMDA-8007 Health+™ High Density Polyethylene Resin is a narrow molecular weight distribution high density homopolymer designed to offer excellent stiffness, low warpage, good toughness, and good moldability. This resin is ideally suited for injection molded medical devices such as IV kit components and respiratory care as well as caps and closures for pharmaceutical packaging.

- Excellent stiffness
- Low warpage
- Good toughness
- High gloss parts
- Complies with U.S. FDA 21 CFR 177.1520 (c)2.2
- Complies with EU, No 10/2011
- Complies with Canadian HPFB No Objection
- Complies with USP XXIII Class VI
- Complies with Drug Master File Listing
- Consult the regulations for complete details.

Additive

- Antiblock: No
- Slip: No
- Processing aid: No

Properties

Physical	Nominal Value	Unit (English)	Nominal Value	Unit (SI)	Test Method ¹
Density	0.965	g/cm ³	0.965	g/cm ³	ASTM D792
Base Density ²	0.965	g/cm ³	0.965	g/cm ³	Dow Method
Melt Index					ASTM D1238
190°C/2.16 kg	8.3	g/10 min	8.3	g/10 min	
190°C/21.6 kg	180	g/10 min	180	g/10 min	
Environmental Stress-Cracking Resistance (ESCR) ³					ASTM D1693
122°F (50°C), 100% Igepal, F50	2.00	hr	2.00	hr	

1. ASTM: American Society for Testing and Materials
2. Base density is estimated using the assumption that every 1000 ppm of antiblock in the finished product raises the density of the polymer by 0.0006 g/cm³. Base density is the estimated density of the polymer if it did not contain any antiblock.
3. Molded and tested in accordance with ASTM D4976.

These are typical properties only and are not to be construed as specifications. Users should confirm results by their own tests.

Properties (Cont.)

Mechanical	Nominal Value	Unit (English)	Nominal Value	Unit (SI)	Test Method
Tensile Strength ³					ASTM D638
Yield	4500	psi	31.0	MPa	
Break	2600	psi	17.9	MPa	
Tensile Elongation ³					ASTM D638
Yield	6.0	%	6.0	%	
Break	350	%	350	%	
Flexural Modulus - 2% Secant ³	205000	psi	1410	MPa	ASTM D790B
Films					
Film Thickness - Tested	1		25	µm	
Film Puncture Resistance (1.0 mil (25 µm))	7.00	ft-lb/in ³	0.579	J/cm ³	Dow Method
Secant Modulus					ASTM D882
2% Secant, MD : 1.0 mil (25 µm), Cast Film	116000	psi	798	MPa	
2% Secant, TD : 1.0 mil (25 µm), Cast Film	136000	psi	935	MPa	
Tensile Strength					ASTM D882
MD : Yield, 1.0 mil (25 µm), Cast Film	2950	psi	20.4	MPa	
TD : Yield, 1.0 mil (25 µm), Cast Film	3240	psi	22.4	MPa	
Tensile Elongation					ASTM D882
MD : Break, 1.0 mil (25 µm), Cast Film	670	%	670	%	
TD : Break, 1.0 mil (25 µm), Cast Film	490	%	490	%	
Dart Drop Impact					ASTM D1709A
1.0 mil (25 µm), Cast Film	24	g	24	g	
Elmendorf Tear Strength					ASTM D1922
MD : 1.0 mil (25 µm), Cast Film	36	g	36	g	
TD : 1.0 mil (25 µm), Cast Film	160	g	160	g	
Impact					
Tensile Impact Strength ^{3,4}	80.0	ft-lb/in ²	168	kJ/m ²	ASTM D1822
Hardness					
Durometer Hardness ³ (Shore D)	61		61		ASTM D2240
Thermal					
Deflection Temperature Under Load ³					ASTM D648
66 psi (0.45 MPa), Unannealed	183	°F	83.9	°C	
Brittleness Temperature ³	< -105	°F	< -76.1	°C	ASTM D746
Vicat Softening Temperature	268	°F	131	°C	ASTM D1525
Melting Temperature (DSC)	271	°F	133	°C	Dow Method
Peak Crystallization Temperature (DSC)	248	°F	120	°C	Dow Method
Optical					
Gloss (45°, 1.00 mil (25.4 µm), Cast Film)	75		75		ASTM D2457
Haze (1.00 mil (25.4 µm), Cast Film)	8.00	%	8.00	%	ASTM D1003
Extrusion					
Melt Temperature	500	°F	260	°C	

4. Type S

Properties (Cont.)

Extrusion Notes	Nominal Value	Unit (English)	Nominal Value	Unit (SI)	Test Method
Fabrication Conditions for Cast Film:					
• Screw A, Size: 2 in. (51 mm); 30:1 L/D					
○ Screw Speed: 39 rpm					
• Screw B, Size: 2.5 in. (63.5 mm); 30:1 L/D					
○ Screw Speed: 39 rpm					
• Screw C, Size: 2.5 in. (63.5 mm); 30:1 L/D					
○ Screw Speed: 39 rpm					
• Screw D, Size: 2.5 in. (63.5 mm); 30:1 UD					
○ Screw Speed: 39 rpm					
• Screw E, Size: 2 in. (51 mm); 30:1 L/D					
○ Screw Speed: 39 rpm					
• Screw Type: DSB II					
• Melt Temperature: 500°F (261°C)					
• Chill Roll Temperature: 70°F (21°C)					
• Line Speed: 400 fpm (123 m/min)					
• Output: 426 lb/hr					
• Die width: 36 in. (914 mm)					
• Die gap: 25 mil (0.6 mm)					

Product Stewardship

The Dow Chemical Company and its subsidiaries ("Dow") has a fundamental concern for all who make, distribute, and use its products, and for the environment in which we live. This concern is the basis for our Product Stewardship philosophy by which we assess the safety, health, and environmental information on our products and then take appropriate steps to protect employee and public health and our environment. The success of our Product Stewardship program rests with each and every individual involved with Dow products -from the initial concept and research, to manufacture, use, sale, disposal, and recycle of each product.

Customer Notice

Dow strongly encourages its customers to review both their manufacturing processes and their applications of Dow products from the standpoint of human health and environmental quality to ensure that Dow products are not used in ways for which they are not intended or tested. Dow personnel are available to answer your questions and to provide reasonable technical support. Dow product literature, including safety data sheets, should be consulted prior to use of Dow products. Current safety data sheets are available from Dow.

Medical Applications Policy

NOTICE REGARDING MEDICAL APPLICATION RESTRICTIONS: Dow will not knowingly sell or sample any product or service ("Product") into any commercial or developmental application that is intended for:

- long-term or permanent contact with internal bodily fluids or tissues. "Long-term" is contact which exceeds 72 continuous hours;
- use in cardiac prosthetic devices regardless of the length of time involved ("cardiac prosthetic devices" include, but are not limited to, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems, and ventricular bypass-assisted devices);
- use as a critical component in medical devices that support or sustain human life; or
- use specifically by pregnant women or in applications designed specifically to promote or interfere with human reproduction.

**Medical
Applications Policy
(Cont.)**

Dow requests that customers considering use of Dow products in medical applications notify Dow so that appropriate assessments may be conducted. Dow does not endorse or claim suitability of its products for specific medical applications. It is the responsibility of the medical device or pharmaceutical manufacturer to determine that the Dow product is safe, lawful, and technically suitable for the intended use. **DOW MAKES NO WARRANTIES, EXPRESS OR IMPLIED, CONCERNING THE SUITABILITY OF ANY DOW PRODUCT FOR USE IN MEDICAL APPLICATIONS.**

Contact:

www.dow.com/contact

NOTICE: No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, the Customer is responsible for determining whether products and the information in this document are appropriate for the Customer's use and for ensuring that the Customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Dow assumes no obligation or liability for the information in this document. **NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.**

NOTICE: If products are described as "experimental" or "developmental": (1) product specifications may not be fully determined; (2) analysis of hazards and caution in handling and use are required; (3) there is greater potential for Dow to change specifications and/or discontinue production; and (4) although Dow may from time to time provide samples of such products, Dow is not obligated to supply or otherwise commercialize such products for any use or application whatsoever.

NOTICE: This data is based on information Dow believes to be reliable, as demonstrated in controlled laboratory testing. They are offered in good faith, but without guarantee, as conditions and method of use of Dow products are beyond Dow's control. Dow recommends that the prospective user determine the suitability of these materials and suggestions before adopting them on a commercial scale.

To the best of our knowledge, the information contained herein is accurate and reliable as of the date of publication, however we do not assume any liability for the accuracy and completeness of such information.

This document is intended for use within Asia Pacific, Latin America, North America.

