



RHOPLEX™ E-32 NP and RHOPLEX E-358 Emulsions

Versatile, Solvent-Resistant, Durable, Acrylic Binders for Nonwovens

Regional Product Availability

- North America

Description

RHOPLEX™ E-32 NP and RHOPLEX E-358 Acrylic Emulsions are self-crosslinking polymers which offer excellent strength and solvent resistance to both durable and disposable nonwovens. They perform well with synthetic fibers, cellulose and blends and can be used on conventional bonding, drying and curing lines. Both water-based emulsions are hydrophilic, impart an intermediate hand and are suitable where maximum durability to washing or dry cleaning is required.

Typical Applications

These versatile emulsions can be used in various applications including interlinings, wet wipes and home furnishings. They are especially suitable for applications where the bonded web will be subjected to some solvents such as those used in dry cleaning or industrial wipes. In addition, RHOPLEX™ E-32 NP Emulsion and RHOPLEX E-358 Emulsion are able to withstand long term exposure to lotions such as those found in premoistened towelettes. RHOPLEX E-358 Emulsion is supplied as a high solids (60%) emulsion making it suitable for bonding composite nonwovens such as scrim laminates where rapid drying is required.

Key Features

- Excellent solvent resistance to some solvents used in dry cleaning or industrial wipes
- Excellent durability to washing and dry cleaning
- Excellent wet and dry tensile strength
- Intermediate hand

Typical Physical Properties

(These properties are typical but do not constitute specifications.)

Property	RHOPLEX™ E-32 NP Emulsion	RHOPLEX E-358 Emulsion
Appearance	Milky-white liquid	Milky white liquid
Type	Self-crosslinking acrylic	Self-crosslinking acrylic
Ionic Charge	Nonionic	Nonionic
Solids Content, %	46	60
pH (as packed)	2.5	7.0
Brookfield Viscosity at 25°C, cP	50	300
Glass Transition Temperature, Tg °C (DSC method)	+5	+8
Density, 25°C lb/US gal kg/l	8.8 1.06	8.9 1.07

Typical Performance Features

Table 1 shows that webs bonded with RHOPLEX™ E-32 NP Emulsion and RHOPLEX E-358 Emulsion have excellent tensile strength under both dry and wet conditions. Both the carded rayon and polyester webs bonded with these binders survived 10 wash cycles or 5 commercial dry cleaning cycles, demonstrating their excellent durability. Table 1 also compares the hand and drape-flex of these emulsions. RHOPLEX NW-2744F Emulsion, a general purpose, low formaldehyde, self-crosslinking nonwoven binder with a softer hand ($T_g = -11^\circ\text{C}$), was included for comparison. All webs were bonded, dried, cured, and tested under laboratory conditions.

Table 1 – Properties of Carded Nonwoven Webs^a
Bonded with RHOPLEX™ E-32 NP Emulsion, RHOPLEX E-358 Emulsion
and RHOPLEX NW-2744F Emulsion
(These properties are typical but do not constitute specifications.)

	RHOPLEX™ E-32 NP Emulsion	RHOPLEX E-358 Emulsion	RHOPLEX NW-2744F Emulsion
Rayon Webs			
Tensile, g/inch width (MD/CMD)			
Dry	3000/500	3200/500	2900/500
Water wet	1100/300	1400/300	1200/200
Isopropanol wet	2500/300	2400/400	2000/300
Hand ^b	3.1	3.9	1.9
Drape-Flex ^c , mm	74	79	64
Polyester Webs			
Tensile, g/inch width (MD/CMD)			
Dry	4300/1100	4500/1300	4200/1000
Water wet	2700/600	2600/700	2400/600
Isopropanol wet	1700/400	1800/400	1000/400
Hand ^b	2.3	2.3	1.0
Drape-Flex, mm	110	114	92

^aPrebonded with 0.25% polyvinyl alcohol; fiber/binder

^bAverage rating of 7 panelists; lower numbers = softer hand.

^cLength of unsupported sample strips (MD) required for a 41.5° overhang.

Formulation Guidelines

Crosslinking

As self-crosslinking acrylic emulsions, neither RHOPLEX™ E-32 NP Emulsion nor RHOPLEX E-358 Emulsion require the addition of an external crosslinking agent for durability or wet strength. However where maximum solvent resistance is required, a thermosetting resin such as methylated melamine formaldehyde resin at 0.5 to 3% solids on emulsion solids can be used.

Catalyst

Acid catalysts such as ammonium nitrate and oxalic acid can be used to accelerate the cure of RHOPLEX E-32 NP Emulsion and RHOPLEX E-358 Emulsion where curing capacity is limited. The following levels of catalyst are recommended:

Catalyst	Concentration (solids on emulsion solids)	Comment
oxalic acid	0.5%	Add as a 10% solution
ammonium nitrate	1.5%	Add as a 25% solution

Formulation Guidelines (cont.)

Surfactant

A nonionic surfactant is recommended in the formulation to achieve better wetting of the fibers. This surfactant should be used at a starting level of 0.5% solids on polymer solids and diluted with at least 3 times its weight of warm water before being added to the formulation. An anionic surfactant should be used where rewetting properties in the end product are desirable. The same solids level and predilution can be used.

Defoamer

A general purpose defoamer is recommended with RHOPLEX™ E- 32 NP or RHOPLEX E-358 Emulsion at a starting level of 0.05 to 0.1% (product as supplied) on the total weight of the formulation. Prior to use, any defoamer should be pre-emulsified with at least an equal weight of warm water and added to the emulsion, under agitation, before other compounding agents.

pH

To maximize emulsion shear stability, the pH of the bath should be adjusted to 8.0 to 8.5 with a volatile base such as ammonium hydroxide.

Starting Point Formulations

The following formulations are offered as starting points for general purpose polyester nonwovens. For a specific balance of properties, recommendations will be provided upon request.

General Purpose Durable Polyester Nonwoven Formulation Using RHOPLEX™ E-32 NP Emulsion or RHOPLEX E-358 Emulsion Binder

Ingredients in Order of Addition	Parts Product by Weight (as supplied)		Parts Product on a Solids Basis	
Water	67.04	74.34	—	—
General purpose defoamer	0.10	0.10	0.10	0.10
Warm water premix	0.10	0.10	—	—
Nonionic Surfactant	0.07	0.07	0.07	0.07
Warm water premix	0.21	0.21	—	—
RHOPLEX E-32 NP Emulsion	31.60	—	14.55	—
RHOPLEX E-358 Emulsion	—	24.30	—	14.57
Ammonium nitrate, (25%)	0.88	0.88	0.22	0.22
Ammonium hydroxide	to pH 8.0 to 8.5	to pH 8.0 to 8.5		
Total	100.00	100.00	14.94	14.96

Product Stewardship

The Dow Chemical Company and its subsidiaries ("Dow") has a fundamental concern for all who make, distribute, and use its products, and for the environment in which we live. This concern is the basis for our Product Stewardship philosophy by which we assess the safety, health, and environmental information on our products and then take appropriate steps to protect employee and public health and our environment. The success of our Product Stewardship program rests with each and every individual involved with Dow products — from the initial concept and research, to manufacture, use, sale, disposal, and recycle of each product.

Customer Notice

Dow strongly encourages its customers to review both their manufacturing processes and their applications of Dow products from the standpoint of human health and environmental quality to ensure that Dow products are not used in ways for which they are not intended or tested. Dow personnel are available to answer your questions and to provide reasonable technical support. Dow product literature, including safety data sheets, should be consulted prior to use of Dow products. Current safety data sheets are available from Dow.

Medical Applications Policy

NOTICE REGARDING MEDICAL APPLICATION RESTRICTIONS: Dow will not knowingly sell or sample any product or service ("Product") into any commercial or developmental application that is intended for:

- a. long-term or permanent contact with internal bodily fluids or tissues. "Long-term" is contact which exceeds 72 continuous hours;
- b. use in cardiac prosthetic devices regardless of the length of time involved ("cardiac prosthetic devices" include, but are not limited to, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems, and ventricular bypass-assisted devices);
- c. use as a critical component in medical devices that support or sustain human life; or
- d. use specifically by pregnant women or in applications designed specifically to promote or interfere with human reproduction.

Dow requests that customers considering use of Dow products in medical applications notify Dow so that appropriate assessments may be conducted.

Dow does not endorse or claim suitability of its products for specific medical applications. It is the responsibility of the medical device or pharmaceutical manufacturer to determine that the Dow product is safe, lawful, and technically suitable for the intended use. **DOW MAKES NO WARRANTIES, EXPRESS OR IMPLIED, CONCERNING THE SUITABILITY OF ANY DOW PRODUCT FOR USE IN MEDICAL APPLICATIONS.**

Disclaimer

NOTICE: No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, the Customer is responsible for determining whether products and the information in this document are appropriate for the Customer's use and for ensuring that the Customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Dow assumes no obligation or liability for the information in this document. **NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.**

NOTICE: If products are described as "experimental" or "developmental": (1) product specifications may not be fully determined; (2) analysis of hazards and caution in handling and use are required; (3) there is greater potential for Dow to change specifications and/or discontinue production; and (4) although Dow may from time to time provide samples of such products, Dow is not obligated to supply or otherwise commercialize such products for any use or application whatsoever.

Additional Information

North America		Europe/Middle East	+800-3694-6367
U.S. & Canada:	1-800-441-4369		+31-11567-2626
	1-989-832-1426	Italy:	+800-783-825
Mexico:	+1-800-441-4369		
Latin America		South Africa	+800-99-5078
Argentina:	+54-11-4319-0100		
Brazil:	+55-11-5188-9000		
Colombia:	+57-1-219-6000	Asia Pacific	+800-7776-7776
Mexico:	+52-55-5201-4700		+603-7965-5392

www.dowplastics.com

This document is intended for use within North America.
Published July, 2013.
© 2013 The Dow Chemical Company

