



# RECYCLED PLASTICS FOR PERFORMANCE GRADED ASPHALTS

C.J. DuBois\*, HAYLEY BROWN, RISHI MUNJ, CRISTINA SERRAT

DOW INC.

PACKAGING & SPECIALTY PLASTICS

DOW TEXAS INNOVATION CENTER, LAKE JACKSON, TX

*July 15<sup>th</sup>, 2019*

# ACKNOWLEDGEMENTS

---

- Dow

- Gerardo Cespedes
- Sean Doughty
- Ann Johnson
- Preston McDaniel
- Leslie O’Leary
- Cyndi Rickey


- Testing Support - Andrew Hanz, MTE

- Commercial Partners

- Martin Asphalt
- American Materials
- Vernor Material & Equipment
- Bit-Mat Products/K-Tech Specialty Coatings
- Central Asphalt - Fisher Companies
- Midland County Road Commission



## What applications are PLASTICS used?



JASON TREAT AND RYAN WILLIAMS, NGM STAFF  
SOURCE: ROLAND GEYER, UNIVERSITY OF CALIFORNIA, SANTA BARBARA

## RECYCLING RATES IN US (2015 EPA DATA)



### Key Commodities

#### Recycling Rates

- Paper and paperboard recycling was 66.6%
- Metals recycling was 34.3%
- Glass recycling was 26.4%
- Plastics recycling was 9.1%
  - PET bottles and jars recycling was 29.9%
  - HDPE Natural (white translucent) bottle recycling was 30.3%

## INTEREST IN RECYCLED PLASTICS IS GROWING

---

- Recycled plastic use in pavement has bipartisan support in US House and Senate
- US Senate Environmental and Public Works Committee is considering funding research to study recycled plastics as part of the 2019 Highway Bill
- Save Our Seas 2.0 also has research monies allocated in the latest draft
- Key stakeholder groups such as AI, NAPA, and NCAT have kicked-off work groups








# WHAT COMPONENTS ARE WE TALKING ABOUT?



# POLYETHYLENE (PE) IN ASPHALT BINDERS

- Pure saturated hydrocarbon in most cases, but insoluble in asphalt
- Semi-crystalline: Poorer intermediate and low temperature performance
- Elastic properties of a PE-modified binder are inferior
- Commercial attempts have been unsuccessful

Type	Process	MWD	SCB	LCB	Co-monomer	Description
LDPE	Free Radical	Broad	Back-biting	Some	None	
ECP EVA, EBA	Free Radical	Broad	Back-biting	Some	Polar	
HDPE	Catalyst	Broad	Little	None	None	
ZN-LLDPE	Catalyst	Broad	$\alpha$ -olefin	None	$\alpha$ -olefin	
mLLDPE	Catalyst	Narrow	$\alpha$ -olefin	None or Sparse	$\alpha$ -olefin	

Can a compatibilizer solve separation and improve low/intermediate temperature performance while enabling the blend to meet all other performance properties?






## SUMMARY

---

- RET enables the use of polyethylene-rich recycled plastics (RPE) in Performance Graded Asphalts
  - Exceed TX DOT PG 70-22 and MDOT PG64-28P performance specifications
- Alone RPE does not pass
  - ASTM D5976 – 48 hour separation test
  - AASHTO M320 or M332 – Performance Grading
- Binders containing RPE with RET meet above
  - Including intermediate and low temperature performance criteria

# RET REACTS CHEMICALLY WITH ASPHALT FUNCTIONAL GROUPS

## Reactive terminal functionality of bitumen



Non-Polar/Polar sections → soluble in asphalt  
 Reactive → elastic properties  
 Controlled crystallinity → tunable temperature performance







## EXPERIMENTAL SUMMARY




## DESIGN OF EXPERIMENT


- Two asphalt binders – PADD 2 (Marathon Detroit) and PADD 3 (Valero)
- One RPE for each
  - Valero – linear low density PE-rich system (LLDPE)
  - Marathon – low density PE-rich system (LDPE)
- Partial factorial DOE chosen to balance exploration of RPE/RET dosage interaction and minimize experiments
  - PPA fixed at 20 wt % of RET



# ASTM D5976 (48 HOUR SEPARATION TEST) – RET IMPROVES SEPARATION VALUES





PADD 3 binder exhibits a large response vs RET and RPE dosage




PADD 2 binder exhibits minimal response vs dosage

Separation - PADD 2 and 3 binders display increased with RPE and decreased with RET



# OPTICAL MICROSCOPY COMPARISON OF MODIFIED ASPHALT – PADD 3 BINDER

## Low Magnification epi-Fluorescence Optical Images



- No distinguishable differences between base binder and RET-only sample
- RPE-only sample displayed distinguishable domains
- Combination of RPE and RET demonstrated differences vs RPE-control


Acknowledgement – Ann Johnson and Preston McDaniel




# LOW/INTERMEDIATE TEMPERATURE TESTING




# INTERMEDIATE TEMPERATURE TESTS – ALL DOSAGES MET SPECIFICATION




PADD 3 binder similar response  
vs dosage




PADD 2 and 3 binders display  
increasing values with RPE and  
decreasing with RET




PADD 2 binder similar response  
vs dosage




# LOW TEMPERATURE TESTS – HIGHER RET % ENABLES RPE TO MEET SPECIFICATION




PADD 3 binder slight RPE dosage effect




PADD 2 and 3 binders display different dosage responses




PADD 2 binder significant dosage effect with RET



# LOW TEMPERATURE TESTS – HIGHER RET % ENABLES RPE TO MEET SPECIFICATION




PADD 3 binder significant RPE dosage effect




PADD 2 binder small RPE dosage effect

PADD 2 and 3 binders display similar dosage responses

PADD 3 Main Effects Plot for m -12°C Fitted Means



PADD 2 Main Effects Plot for -18C m-value Fitted Means







# STIFFNESS-BASED TESTING



# UPPER CONTINUOUS GRADING – BOTH RPE AND RET IMPROVE PERFORMANCE





PADD 3 binder significantly more responsive vs dosage




PADD 2 binder significantly less responsive vs dosage

PADD 2 and 3 binders display increased upper PG with both RPE and RET





# NON-RECOVERABLE CREEP – BOTH MATERIALS IMPROVE PERFORMANCE



PADD 3 binder significantly more responsive vs dosage

PADD 2 and 3 binders display improved  $J_{nr,3.2}$  with both RPE and RET


PADD 2 binder more response to RET vs dosage



# ELASTIC PROPERTY TESTING



# ELASTIC RECOVERY – COMBINATION OF RET AND RPE MEET PERFORMANCE






PADD 3 binder most responsive to RET vs dosage


SBS control with RPE = 52%

PADD 2 and 3 binders display similar dosage responses

PADD 2 binder most responsive to RET vs dosage




# MSCR %R – COMBINATION OF RET AND RPE MEET PERFORMANCE





PADD 3 binder is highly reactive to RET

SBS control with RPE = 52%


PADD 2 and 3 binders most responsive to RET dosage



PADD 2 binder has high reactivity to RET




# PHASE ANGLE – COMBINATION OF RET AND RPE MEET PERFORMANCE




PADD 3 binder is highly reactive to RET


PADD 2 and 3 binders most responsive to RET dosage




PADD 2 binder has high reactivity to RET



# 135°C VISCOSITY – RET HAS THE LARGEST DOSAGE RESPONSE





PADD 3 binder significantly more responsive vs dosage



PADD 2 binder significantly less responsive vs dosage

PADD 2 and 3 binders display increased viscosity with both RPE and RET





## FIELD PROJECTS



# MET TX DOT PG70-22 BINDER SPECIFICATION

---

- Utilized 750 kg of LLDPE-rich recycled plastic in total 1 kT hot mix
- Blend of LLDPE-rich 1.5% Post-Consumer Recycle + 0.6% RET + 0.2% PPA
  - PCR supplier: Avangard Recycling (Houston TX)
- Texas DOT type D (340-DG-D) mix design - 1.50" lift thickness
- 5.2% asphalt binder with 19.1% RAP
- Limestone/dolomite aggregate
- Passed – AASHTO T322 Indirect Tensile (IDT) Strength Test



# FIELD PLACEMENT AT JOB SITE – NO DIFFERENCES THAN NORMAL PROJECT



# THIS IS ONLY A STARTING POINT ...

---

## Planned Future Work

- Mix testing to validate performance - in progress
  - Hamburg
  - IL-SCB
  - IDEAL-CT
  - DCT
- Glover-Rowe/Blackspace study of modified binders
- Optimize formulations to determine maximum recycled plastics loadings in asphalt binders with RET while meeting performance specifications
- More controlled demonstration projects to generate field data!





Any physical properties described in this presentation are typical values and should not to be construed as specifications. Users should confirm results by their own tests.

Any photographs of end-use applications in this document represent potential end-use applications but do not necessarily represent current commercial applications, nor do they represent an endorsement by Dow of the actual products. Further, these photographs are for illustration purposes only and do not reflect either an endorsement or sponsorship of any other manufacturer for a specific potential end-use product or application, or for Dow, or specific products manufactured by Dow.

The data provided in this slide presentation was collected during 2019, and is included to illustrate approximate trends in the industry. The data provided in this slide presentation is given in good faith for informational purposes only. Dow assumes no obligation or liability for the industry data presented herein. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, the user is responsible for determining whether products and the information in this document are appropriate for the user's use and for ensuring that the user's workplace and disposal practices are in compliance with applicable laws and other government enactments. The product(s) shown in this literature may not be available for sale and/or available in all geographies where Dow is represented. The claims made may not have been approved for use in all countries. References to "Dow" or the "Company" mean the Dow legal entity selling the products to the customer unless otherwise expressly noted.





Seek

Together™



Thank you