



Technical Data Sheet

XIAMETER™ MEM-0039 Emulsion

Aqueous emulsion of polydimethylsiloxane

Features & Benefits

- Ready to use non ionic emulsion
- Provides gloss and water repellency
- Good wetting and slip characteristics
- General purpose release agent
- Does not contain alkylphenolethoxylates (APEO)
- Complies with Detergent Regulation (EC) No. 648/2004
- Good emulsion stability after extended periods at 50°C (4 weeks)
- Good dilution stability. Dilutions up to 130 parts water to 1 part emulsion are possible so that optimum concentration of silicone may be used with no excess waste
- Good freeze-thaw stability (5 cycles)

Applications

XIAMETER™ MEM-0039 Emulsion has been specially formulated for use as polish ingredient and release agent/lubricant either “as received” or “pre-diluted” with water. Its formulation, stability and efficiency can lead to a variety of applications. These include:

- As ingredient in polishes, XIAMETER MEM-0039 Emulsion is used to provide good gloss with minimum smear in both car and furniture polish formulations
- Mold release of:
 - Rubber or plastic parts (stoppers, screw tops, bungs, etc.)
- Lubrication of:
 - Extruded rubber parts; conveyor belts
- Textile lubricant:
 - Yarn manufacture
 - Sewing thread lubrication
 - Hosiery manufacture
 - Sewing needle lubrication
 - Glass fabric exhaust filters

Typical Properties

Specification Writers: These values are not intended for use in preparing specifications.

| Test ¹ | Property | Unit | Result |
|-------------------|--------------------------------|-------|--------------|
| 0176 | Appearance | | White liquid |
| 0862 | Non volatile content | % w/w | 35.50–38.0 |
| 0001 | Specific gravity @ 77°F (25°C) | | 1.0 |

1. CTM: Corporate Test Method, copies of CTM's are available on request.

UNRESTRICTED – May be shared with anyone

™Trademark of The Dow Chemical Company (“Dow”) or an affiliated company of Dow

XIAMETER™ MEM-0039 Emulsion

© 2017 The Dow Chemical Company. All rights reserved.

Typical Properties (Cont.)

| Test | Property | Unit | Result |
|------|-----------------|------|-----------|
| 0007 | pH | | 6.5–8.5 |
| | Emulsifier type | | Non-ionic |
| | Diluent | | Water |

Description XIAMETER MEM-0039 Emulsion is a 35% actives non-ionic emulsion formulated with a polydimethylsiloxane. Because its nonionic nature, it can be used in a variety of systems, such as nonionic, anionic, cationic surfactant or polymer systems without forming a complex.

How To Use XIAMETER MEM-0039 Emulsion can be used as received or in a diluted form.

For use as a release/lubricant XIAMETER MEM-0039 Emulsion may be applied at received in a diluted form by the conventional methods of spraying, dipping, wiping or brushing. Low hardness water should be used for dilution. A typical dilution is XIAMETER MEM-0039 Emulsion (1 part w/w) to water (20 parts w/w) but the user should determine the best concentration and application method on a small scale before production.

For use as fabric finish agent XIAMETER MEM-0039 Emulsion can be applied to fabric by padding. The amount of emulsion required will depend on the fabric constructions and type of fabric used (natural, synthetic). Generally, between 10 g/L and 40 g/L bath concentration is recommended.

Procedure For Padding

1. Scour goods in a non-ionic detergent and rinse thoroughly. Follow with an acid rinse using 2 g/L of 80% acetic acid for 5 minutes. This will neutralize any alkali residues from previous processes that may cause pad bath instability and lead to oil spots on fabrics or gel on the rollers.
2. If crease resist resins or fillers are used, dilute in the mixing tank in accordance with the manufacturers' instructions. If hot, cool to below 30°C before adding the silicone emulsion.
3. Pre-dilute the required amount of XIAMETER MEM-0039 Emulsion with an approximately equal weight of cold water and add to the mixing tank.
4. If crease resist resin catalyst is used, pre-dilute with an equal weight of water and add to the mixing tank.
5. Top up to final volume with cold water.

Precautions During Use

- Start with clean mixing tank, delivery lines, pad box and rolls.
- Dilute the emulsion with cold water only.
- Do not use a high shear stirrer when making finishing liquor.

UNRESTRICTED – May be shared with anyone

®™ Trademark of The Dow Chemical Company ("Dow") or an affiliated company of Dow

XIAMETER™ MEM-0039 Emulsion

© 2017 The Dow Chemical Company. All rights reserved.

How To Use (Cont.)

ATTENTION: Sample formulations are provided for illustrative purposes only. Dow does not warrant their merchantability, fitness for use, performance, efficacy, safety or freedom from patent infringement.

They are not commercial formulations and have not been subjected to extensive testing. It is your responsibility to thoroughly test any formulation before use.

Handling Precautions

PRODUCT SAFETY INFORMATION REQUIRED FOR SAFE USE IS NOT INCLUDED IN THIS DOCUMENT. BEFORE HANDLING, READ PRODUCT AND SAFETY DATA SHEETS AND CONTAINER LABELS FOR SAFE USE, PHYSICAL AND HEALTH HAZARD INFORMATION. THE SAFETY DATA SHEET IS AVAILABLE ON THE DOW WEBSITE AT WWW.CONSUMER.DOW.COM, OR FROM YOUR DOW SALES APPLICATION ENGINEER, OR DISTRIBUTOR, OR BY CALLING DOW CUSTOMER SERVICE.

Usable Life And Storage

XIAMETER MEM-0039 Emulsion will freeze so adequate precautions should be taken. In case of freezing, thaw at room temperature before use to reconstitute. To prevent freezing, store above 5°C.

When stored at or below 35°C in the original unopened containers, this product has a usable life of 15 months from the date of production.

Limitations

This product is neither tested nor represented as suitable for medical or pharmaceutical uses.

Health And Environmental Information

To support customers in their product safety needs, Dow has an extensive Product Stewardship organization and a team of product safety and regulatory compliance specialists available in each area.

For further information, please see our website, www.consumer.dow.com or consult your local Dow representative.

<http://www.xiameter.com>

LIMITED WARRANTY INFORMATION – PLEASE READ CAREFULLY

The information contained herein is offered in good faith and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information should not be used in substitution for customer's tests to ensure that our products are safe, effective, and fully satisfactory for the intended end use. Suggestions of use shall not be taken as inducements to infringe any patent.

Dow's sole warranty is that our products will meet the sales specifications in effect at the time of shipment.

Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted.

TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, DOW SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY.

DOW DISCLAIMS LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

