



MyTrends

Engage & Embrace

We celebrate diversity and individuality while being responsible and fully engaged. Today's motto: contribute to society in a positive way, embrace our well-being and the environment and shape a society with positive values. Our credo: DO.

Glam Sunset After-Sun Body Cream CPF 4124

Attributes

- Moisturizing
- Lightweight
- Non-greasy feel
- Quick absorption
- Shimmering effect

Featured Products

- DOWSIL™ 2501 Cosmetic Wax
- ACULYN™ 33A Rheology Modifier
- ACULYN™ Siltouch Rheology Modifier
- DOWSIL™ HMW 2220 Non-Ionic Emulsion

Visit consumer.dow.com/personalcare and dow.com/en-us/industries/consumer/personal-care (organic solutions) to see Dow at work and learn more about the technologies that make consumer products better.

DOW DISCLAIMS LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

®™ Trademark of The Dow Chemical Company (Dow) or an affiliated company of Dow

© 2019 The Dow Chemical Company. All rights reserved.

Phase	Trade Name / Supplier	INCI Name	Wt. %
A	Deionized Water	Water / Aqua	75.10
	DOWSIL™ 2501 Cosmetic Wax / Dow	Bis-PEG-18 Methyl Ether Dimethyl Silane	2.00
	ACULYN™ 33A Rheology Modifier / Dow	Acrylates Copolymer	1.50
		Glycerin	5.00
B	Cetiol SB 45 / BASF	Butyrospermum Parkii Butter (shea butter)	1.00
	Cetiol LC / BASF	Coco-Caprylate / Caprate	7.00
	Brij S20 / Croda	Steareth-20	1.00
C	Timiron Splendid Gold / Merck	Titanium Dioxide (and) Mica (and) Silica	1.00
	ACULYN™ Siltouch Rheology Modifier / Dow	Sodium Acrylate / Sodium Acryloyldimethyl Taurate Copolymer (and) Dimethicone (and) Trideceth-6 (and) PEG / PPG-18 / 18 Dimethicone	2.50
	DOWSIL™ HMW 2220 Non-Ionic Emulsion / Dow	Divinyldimethicone / Dimethicone Copolymer (and) C12-13 Pareth-23 (and) C12-13 Pareth-3	2.00
D	10146-ABS Aloe Extract G / Active Concept	Glycerin & Aqua (and) Aloe Barbadensis Leaf Extract (and) Leuconostoc / Radish Root Ferment Filtrate	1.00
	Euxyl PE 9010 / Schülke & Mayr	Phenoxyethanol (and) Ethylhexylglycerin	0.50
		Sodium Hydroxide (40% solution)	0.10
	122617-Coco Douve / Symrise	Perfume	0.30

Procedure

- Mix phase A ingredients together at 700 rpm. Heat phase A to 70°C.
- Heat phase B ingredients at 70°C and mix at 500 rpm until homogeneous.
- Add phase B to phase A under mixing at 1000 rpm and then at 4000 rpm with high shear mixer (ex: Silverson).
- Add phase C to phase AB under moderate shear (500 rpm).
- Cool down to 40°C.
- One-by-one, add phase D ingredients to phase ABC under moderate shear (500 rpm).
- If needed, adjust pH to near 6.3

LIMITED WARRANTY INFORMATION – PLEASE READ CAREFULLY

The information contained herein is offered in good faith and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information should not be used in substitution for customer's tests to ensure that our products are safe, effective and fully satisfactory for the intended end use. Suggestions of use shall not be taken as inducements to infringe any patent.

Dow's sole warranty is that our products will meet the sales specifications in effect at the time of shipment.

Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted.

TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, DOW SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY. 27-2304-01



consumer.dow.com