



ACUSOL™ 820 Rheology Modifier/Stabilizer

Description

ACUSOL™ 820 Rheology Modifier/Stabilizer is a Hydrophobically modified Alkali Soluble acrylic polymer Emulsion (HASE) with unusually high aqueous thickening and stabilising efficiency. When neutralized to a pH above 7 by adding alkalis, ACUSOL 820 thickens instantly. The instantaneous effect on viscosity and easy incorporation of ACUSOL 820 into alkaline cleaner formulations offer savings in valuable production time that cannot be matched by carbomer or cellulosic thickeners, requiring predissolution and elimination of lumps.

Applications

Working by association, ACUSOL 820 can also thicken solutions containing high levels of surfactants at low pH. This unique performance is achieved by acidifying a neutralized surfactant-containing formulation with a dilute organic or mineral acid.

Physical Properties

The following are typical properties of ACUSOL™ 820 Rheology Modifier/Stabilizer; **they are not to be considered product specifications.**

Appearance: Off white milky emulsion
 Polymer type: Associative anionic acrylic
 Solids (%): 30
 pH (as supplied): 2.7
 Density: 1.06
 Viscosity (as supplied): 15 Brookfield mPa·s/cPs
 Acid value: 11.7 (mls. N/10 NaOH per g product)

Features and Benefits

Features	Benefits
Anionic	Can be thickened instantly with any alkali. Compatible with both non-ionic and anionic surfactants, builders and fillers.
Liquid	Supplied as a low viscosity liquid emulsion, it is very easy to handle. No predissolution, elimination of lumps or warming required.
Associative nature	Association may occur with other formulation components giving enhanced viscosity and stability.
Rheology	Gives pseudoplastic (shear thinning) rheology, similar to cellulose but maintains higher viscosity for higher shear rates.
Emulsion technology	Water-based polymerization. No residual solvents. No residual organic initiators.
Instant neutralization	Permits continuous manufacturing process through in-line static mixers.
Gel appearance	Gives clear gels or solutions.
Microbial resistance	Being a synthetic polymer, ACUSOL™ 820 Rheology Modifier/Stabilizer is inherently resistant to microbes and enzymes that can degrade cellulosic thickeners, leading to loss of viscosity.
Salt tolerance	Compatible with high levels of salts and electrolytes commonly used in household and institutional formulations.

UNRESTRICTED –May be shared with anyone

©™ Trademark of The Dow Chemical Company ("Dow") or an affiliated company of Dow

ACUSOL™ 820 Rheology Modifier/Stabilizer

Recommended Applications

ACUSOL™ 820 Rheology Modifier/Stabilizer is highly cost-effective for the following applications:

- Emulsion cleaners
- Glass cleaners
- Hand dishwash liquid detergents
- Hard surface and floor cleaners
- Liquid abrasive cleaners
- Liquid laundry detergents
- Oven cleaners
- Paint strippers
- Waterless cleaners
- White-wall tire cleaners

Formulating Tips

ACUSOL™ 820 Rheology Modifier/Stabilizer is compatible with surfactants, solvents, oils, salts and other ingredients commonly found in detergent and cleaner products. Formulators of detergents and cleaners will have no difficulty in discovering the best way to incorporate ACUSOL 820 into their own specific products.

General Mixing Procedure

Operating flexibility is provided by the physical characteristics of the product (low viscosity liquid before neutralization), and its high thickening efficiency allows varying operating procedures. The following mixing procedure meets most formulating needs:

1. Introduce ACUSOL™ 820 polymer into the formulation water.
This should provide at least a threefold dilution of the polymer.
2. Add the nonionic surfactants (if any).
3. Add the anionic surfactants (if any)—low pH first.*
4. Add builders, fillers, particulates.
5. Add dyes, then perfume.
6. Neutralize with the chosen alkali.

* In the case of strongly acidic components, such as sulphonic acids, it is preferable to disperse this component in the system and partially neutralize (e.g. - to pH about 4-5) prior to addition of the polymer.


Rapid Mixing Technique

ACUSOL™ 820 polymer undergoes instantaneous thickening when a base is added. An in-line mixing technique using a static mixer along with a simple pump affords a convenient, rapid means of producing thickened solutions and gels. The solutions prepared by this technique are free from air bubbles.

For example, pumping solutions of ACUSOL 820 (4% polymer solids) and sodium hydroxide (0.74%) at equal rates through a static mixer gave 115 kg/hr of a clear foam-free gel (Brookfield viscosity 2×10^6 mPa·s at 0.5 rpm) containing 2% ACUSOL 820 solids. A small laboratory pump run at maximum speed gave the same output rate as in pumping deionized water. Although this example used only two feed streams, more feeds could be combined, depending on the type of formulation and the compatibility of the ingredients (see Fig. 1, next page).

Figure 1

Schematic Representation of an In-Line Mixer




Performance Properties

Thickening Efficiency

ACUSOL™ 820 Rheology Modifier/Stabilizer is a low viscosity dispersion that becomes a highly viscous clear solution when neutralized with alkali. Figure 2 shows the pH profile of sodium hydroxide neutralized ACUSOL 820 where a stable viscosity plateau is observed, and viscosity drops at pH values below 7.5 and above 12.5. This pH/viscosity profile may change in the presence of surfactants (see “Associative Nature” under Features and Benefits).

Figure 2

Viscosity / pH Response of ACUSOL™ 820 Rheology Modifier/Stabilizer at 0.8% active polymer content



UNRESTRICTED –May be shared with anyone

©™ Trademark of The Dow Chemical Company (“Dow”) or an affiliated company of Dow

ACUSOL™ 820 Rheology Modifier/Stabilizer

Performance
Properties
 Thickening Efficiency (cont'd)

Figure 3 shows the thickening performance at various Brookfield rotational speeds as a function of the polymer concentration.

Figure 4 compares its efficiency with that of a cellulosic and a carbomer thickener, demonstrating its pH tolerance. Besides sodium hydroxide, other bases, such as ammonia, soda ash (Na_2CO_3) and TEA, can be used as neutralizing agents.

Figure 3
Viscosity of ACUSOL™ 820
Rheology Modifier/Stabilizer Solutions
 as a function of polymer concentration





Figure 4
Effect of Alkali Concentration on Viscosity
 (1.25% ACUSOL™ 820 Rheology Modifier/Stabilizer Al)




UNRESTRICTED –May be shared with anyone

©™ Trademark of The Dow Chemical Company ("Dow") or an affiliated company of Dow
 ACUSOL™ 820 Rheology Modifier/Stabilizer

Effect of Temperature on Viscosity

As with most formulations, products thickened with ACUSOL™ 820 Rheology Modifier/Stabilizer will generally show a drop in viscosity with increasing temperature (Figure 5). This effect, which is common to most thickeners, is reversible with a decrease in temperature.


Figure 5



Effect of Shear Rate on Viscosity

The rheology of ACUSOL™ 820 polymer is extremely pseudoplastic (shear thinning). Under good mixing conditions, ACUSOL 820 thickens instantly upon adding a base and thereby allows rapid preparation of solutions and products. Viscosity profiles are very similar, irrespective of the base employed. No pre-wetting, high-shear mixing, and long soak times, often required for other thickeners, are needed to dissolve the un-neutralized polymer. The aqueous neutralized solutions are clear, and show shear thinning as well as being shear thinning. Consequently, the solutions are very viscous at low shear rates, as shown in Figure 6.

Figure 6




Associative Nature

ACUSOL™ 820 Rheology Modifier/Stabilizer has long hydrophobic chains that can associate with other hydrophobes present in the formulation (e.g. surfactants, particles etc.). This feature can enhance thickening in the case of low pH formulations, where polymer swelling is limited. The synergistic effect depends on the surfactant concentration: maximum viscosity can be obtained at an optimum concentration. With sodium lauryl sulphate (SLS), for example, the maximum occurs when the ratio of the surfactant to ACUSOL 820 solids level reaches 40% (i.e. a ratio of 0.4:1). Figure 7 illustrates the synergistic effect of ACUSOL 820 in the presence of SLS. In this graph, the polymer concentration required to obtain a given viscosity over a range of surfactant concentrations is shown. For ACUSOL 820, the polymer performance remains good through a wide range of surfactant concentrations, whereas steadily increasing levels of a non-associative polymer are required to maintain a given viscosity.

Figure 7

Relative Efficiency of ACUSOL™ 820 Rheology Modifier/Stabilizer compared with a non-associative polymer




Mixture with Bentonite Clays

The addition of low cost bentonite clays appreciably increases the thickening efficiency of ACUSOL™ 820 Rheology Modifier/Stabilizer. Freestanding gels can be obtained by combining appropriate levels of neutralized thickener with bentonite clays (Figure 8).

Figure 8

Synergistic Effect of Bentonite on ACUSOL™ 820 Rheology Modifier/Stabilizer




Performance Properties (cont'd)

Compatibility with Inorganics

ACUSOL™ 820 Rheology Modifier/Stabilizer can be used even in the presence of relatively high levels of inorganic salts, such as sodium chloride. Efficacy is reduced, but the polymer remains capable of thickening concentrations of salt even at a level of several percent. This is illustrated in Figure 9.

Figure 9



Preparation of Emulsions and Dispersions

Neutralized ACUSOL™ 820 Rheology Modifier/Stabilizer can also be used to make oil-in-water emulsions of organic liquids, such as mineral oil, methylene chloride or kerosene, and to suspend fillers and pigments, such as calcium carbonate, silicate clays and titanium dioxide in water. ACUSOL 820 may be useful in thickening aqueous waste materials and absorbing spills of hazardous wastes as well as in removing water from water-immiscible oils and hydrocarbon solvents.

Handling Precautions

Before using this product, consult the Safety Data Sheet (SDS) for details on product hazards, recommended handling precautions and product storage.

Avoid high-shear pumps when handling this product.

Storage Recommendation

Store product in tightly closed original container at temperatures recommended on the product label.

Keep from freezing. This emulsion product as supplied will irreversibly coagulate upon freezing.

Disposal Considerations

Dispose in accordance with all local, state (provincial) and federal regulations. Empty containers may contain hazardous residues. This material and its container must be disposed in a safe and legal manner.

It is the user's responsibility to verify that treatment and disposal procedures comply with local, state (provincial) and federal regulations.

Stewardship

Dow has a fundamental concern for all who make, distribute, and use its products, and for the environment in which we live. This concern is the basis for our product stewardship philosophy by which we assess the safety, health, and environmental information on our products and then take appropriate steps to protect employee and public health and our environment. The success of our product stewardship program rests with each and every individual involved with Dow products – from the initial concept and research, to manufacture, use, sale, disposal, and recycle of each product.

Customer Notice

Dow strongly encourages its customers to review both their manufacturing processes and their applications of Dow products from the standpoint of human health and environmental quality to ensure that Dow products are not used in ways for which they are not intended or tested. Dow personnel are available to answer your questions and to provide reasonable technical support. Dow product literature, including Safety Data Sheets (SDS), should be consulted prior to use of Dow products. Current Safety Data Sheets are available from Dow.

Contact:

North America: 1-800-447-4369
Latin America: (+55)-11-5188-9000
Europe: (+800)-3-694-6367
(Toll) +31-11567-2626
Asia-Pacific: (+800)-7776-7776
(Toll) +60-3-7965-5392

<http://www.dow.com>

Notice: No freedom from infringement of any patent owned by Dow or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace and disposal practices are in compliance with applicable laws and other government enactments. The product shown in this literature may not be available for sale and/or available in all geographies where Dow is represented. The claims made may not have been approved for use in all countries. Dow assumes no obligation or liability for the information in this document. References to "Dow" or the "Company" mean the Dow legal entity selling the products to Customer unless otherwise expressly noted. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.



UNRESTRICTED –May be shared with anyone

©™ Trademark of The Dow Chemical Company ("Dow") or an affiliated company of Dow
ACUSOL™ 820 Rheology Modifier/Stabilizer